

Supplied with:
USB-C Charging cable



Operation:
Power / Light Mode Switch

- 1: On - Low power
- 2: On - Medium power
- 3: On - High power
- 4: On - Red emergency light
- 5: Power off

Flashing:

When in any light mode, double press the power button to enter flashing mode for that brightness and colour (includes red flashing mode).

Dimmable:

In High/Low/medium light mode, press and hold the power button for 3 seconds to turn on dimmer mode.

Charging:


USB C cable connection.
4 stage charging indicator lights (blue)
Stepped blue flashing light = Charging
Blue constant light = Charged



Power bank to charge mobile devices



Charging Port



Features:



NightSearcher Limited
Unit 4 Applied House, Fitzherbert Spur,
Farlington, Portsmouth, Hampshire,
PO6 1TT, UK
T: +44 (0)23 9238 9774
E: sales@nightsearcher.co.uk

To view and download the full manual in multiple languages please go to <https://nightsearcher.co.uk/en/user-manuals.html> Or scan this QR code.



If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products, bulbs and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf.

All NightSearcher products have a 3-year standard warranty on all manufacturing defects and 1-year warranty on all rechargeable batteries from the date of purchase. Please visit www.nightsearcher.co.uk for extended warranty information, proof of purchase is required.

Product weight	680g
Product size	180x59x155mm
NS Part No.	NSNOVASTAR

